

58513

Installation Instructions

1. Remove screw(s) from old overflow plate and retain.
2. If replacing a 1-hole plate, align slots in adapter to screw hole in drain. Attach using screw from old plate to hold adapter in place.
3. Align screw holes on the new overflow plate and thread new screws into place.
Tighten with screwdriver.

Tools needed for installation: Screwdriver

