

58514

Installation Instructions

1. Remove screw from old overflow plate and retain.
2. If replacing a 2-hole plate, align slots in adapter to screw holes in drain. Attach using screws from old plate to hold adapter in place.
3. Align screw hole on your new overflow plate and thread screw into place.
Tighten with screwdriver.

Tools needed for installation: Screwdriver

