

51117

Installation Instructions

Fits with PartsmasterPro 51114 and 51115 Shower Strainer Drains.

1. Remove existing Basket by pulling up on the shower strainer drain Cover Handle.
2. Remove Cover from Basket.
3. Place Cover on new Basket and reinsert into drain opening.
4. Replace Basket as needed.

