

53019

Installation Instructions

1. Unthread spray head from spray hose and retain all parts.
2. Remove retainer clip and slide old spray head nut from hose.
3. Push hose through spray hose guide so guide can be removed.
4. Unthread hose guide nut with adjustable wrench if necessary.
5. Remove old spray hose guide and install the new hose guide.
6. Place new nut on spray hose and secure with new retainer clip.
7. Place new washers on hose and thread nut onto new spray head.

Tools needed for installation: • Adjustable Pliers

