

53012

Installation Instructions

1. Unthread spray head from spray hose and retain all parts.
2. Push hose through spray hose guide so guide can be removed.
3. Unthread nut with adjustable wrench if necessary.
4. Remove old spray hose guide.
5. Place new nut on spray hose and secure with new retainer clip.
6. Place new washer on hose and thread nut onto new spray head

Tools needed for installation: • Adjustable Pliers

Instrucciones

1. Desenroscar la cabeza rociadora de la manguera rociadora y guardar todas las piezas.
2. Empuje la manguera a través de la guía de la manguera rociadora de manera que pueda remover la guía.
3. Desenrosque la tuerca con llave inglesa ajustable si es necesario.
4. Remover la guía de manguera rociadora usada.
5. Coloque la nueva tuerca en la manguera de rociado y fijela con la nueva presilla retenedora.
6. Coloque la nueva arandela en la manguera y enrosque la tuerca en la nueva cabeza rociadora.

Herramientas necesarias: • Alicates Ajustables

