


58212

Installation Instructions

1. Turn off water supply.
2. Remove handle cap and retaining screw and remove handle by pulling straight out.
3. Remove old flange by unthreading.
4. Remove old nipple by unthreading
5. Install new nipple by threading nut end into bonnet nut.
6. Install new flange by threading nut onto nipple and tightening to wall.
7. Replace handle and tighten with retaining screw.
8. Replace handle cap and turn on water supply.



Tools needed for installation: • Adjustable Wrench • Screwdriver