

58436

Installation Instructions

1. Unthread spray head from spray hose and retain all parts.
2. Push hose through spray hose guide so guide can be removed.
3. Unthread nut with adjustable wrench if necessary.
4. Remove old spray hose guide.
5. Install replacement guide in reverse order and reassemble spray head.

Tools needed for installation: • Adjustable Wrench

Instrucciones

1. Desenrosca la cabeza rociadora de la manguera rociadora y guardar todas las piezas.
2. Empuje la manguera a través de la guía de la manguera rociadora de manera que pueda remover la guía.
3. Desenrosque la tuerca con llave inglesa ajustable si es necesario.
4. Remover la guía de manguera rociadora usada.
5. Instale la guía de repuesto en el orden inverso y vuelva a montar la cabeza rociadora.

Herramientas necesarias: • Llave de tuercas regulable

