

## 58458

### Installation Instructions

Unthread spray head from spray hose and retain all parts.  
Push hose through spray hose guide so guide can be removed.  
Unthread nut with adjustable wrench if necessary.  
Place new nut on spray hose and secure with new retainer clip.  
Place new washer on hose and thread nut onto new spray haad

