

58492B

Installation Instructions

1. Rotate stopper while pulling up until stopper releases.
2. Replace with new stopper.

Tools needed for installation: • None

