

## 58516B

### Installation Instructions

1. Using a screwdriver, remove screw from center of strainer
  2. Insert screwdriver into one of the holes in old strainer and pry off strainer.
  3. Install replacement strainer by pushing firmly into drain opening.
  4. Install replacement screw into center of strainer.
- Tools need for installation:** • Small Screwdriver

