

58143

Installation Instructions

1. Turn off water supply.
2. Remove handle cap and retaining screw.
3. Remove handle by pulling straight up.
4. For Lavatory Faucets: insert stem extension into underside of new handle.
For Tub/Shower Faucets: discard stem extension.
5. Install new handle and tighten with retaining screw.
6. Install new handle cap and turn on water supply.

Tools needed for installation: • Screwdriver

