

## 58196

### Installation Instructions

1. Turn off water supply.
2. Remove handle cap and retaining screw.
3. Remove handle by pulling straight out.
4. Place handle adapter over exposed end of faucet stem.
5. Thread retaining screw into adapter and stem. Tighten set screws on handle adapter.
6. Unthread retaining screw.
7. Place new handle on stem with adapter. Select new retaining screw thread size to fit stem. Tighten handle to stem with new retaining screw.
8. Replace handle cap and turn on water supply.

**Tools needed for installation:** • Screwdriver

