

58386

Installation Instructions

1. Turn off water supply.
2. Remove retaining screw and remove handle by pulling straight out.
3. Unthread set-screw and remove escutcheon plate.
4. Remove retainer nut and pull out old cartridge. Install new cartridge and retainer nut. Do not over tighten.
5. Reinstall escutcheon plate and tighten set-screw.
6. Turn on water supply. Check for leaks.

Tools needed for

installation: • Screwdriver

- Allen Wrench
- Adjustable Wrench

