

58393B

Installation Instructions

1. Turn off water supply.
2. Remove handle by loosening set screw.
3. Remove cap and lift out cartridge.
4. Remove existing seats and springs, and replace with new seats and springs.
Replace o-rings on cartridge.
5. Reassemble faucet in reverse order
6. Turn on water supply. Check for leaks.

Tools needed for installation:

- Allen Wrench
- Adjustable Wrench

