

58529

Installation Instructions

1. Turn off water supply.
2. Remove handle cap and retaining screw from handle.
3. Remove handle by pulling straight out.
4. Unthread flange from nipple and remove flange.
5. Unthread nipple from stem and remove nipple.
6. Using the included shower valve socket wrench, unscrew and pull out stem.
7. Insert seat wrench into faucet, turn counter-clockwise and remove old seat.
8. Place new seat into faucet and tighten with seat wrench.
Using the included shower valve socket wrench, install new stem, ensuring washer is in place under the stem bonnet.
9. Thread nipple onto stem. Thread flange onto nipple until it is flush against the wall.
10. Place new handle on stem, tighten with retaining screw and replace handle cap.
11. Turn on water supply and check for leaks.

