

58574B

Installation Instructions

1. Turn off water supply.
2. Remove handle cap and retaining screw, and remove handle by pulling straight out.
3. Unthread and remove cap assembly.
4. Remove ball and cam by pulling up on ball stem.
5. Replace ball, then place new cam assembly (with rubber cam packing below plastic cam) on top of ball. Make sure that lug on side of cam is inserted into slot on the side of the faucet body. Tighten cap assembly securely.
6. Reassemble handle to faucet.
7. Turn on water and check for leaks.

Tools needed for installation:

- Adjustable Wrench
- Screwdriver

