

58593

Installation Instructions

(Read all instructions carefully
before installing)

Seat replacement is
recommended with new stem
installations.

1. Turn off water supply to
faucet, remove handle cap,
retaining
screw and gently lift off
handle.
2. Unthread flange by turning
counterclockwise.
3. Unthread retaining nut and
remove stem by pulling
straight out.
4. Install new stem, and thread
retaining nut into faucet body.
5. Reinstall flange and sleeve by
tightening set screw.
6. Replace hangle, retaining
screw and handle cap.
7. Turn on water supply and
check for leaks.

Tools needed for installation:

- Screwdriver
- Faucet Seat
Wrench
- Shower Valve Socket
Wrench

