

58065

Installation Instructions

(Read all instructions carefully
before installing)

Seat replacement is
recommended with new stem
installations.

1. Turn off water supply to faucet, remove handle cap, retaining screw and gently lift off handle.
2. Remove old flange and sleeve by loosening set screw.
3. Unthread bonnet and remove stem using shower valve socket wrench.
4. Insert seat wrench into faucet body and turn counterclockwise to remove old seat.
5. Place new seat into faucet body and tighten with seat wrench.
6. Thread new stem unit into faucet body.
7. Reinstall flange and sleeve by tightening set screw.
8. Replace handle, retaining screw and handle cap.
9. Turn on water supply and check for leaks.

Tools needed for installation:

- Screwdriver
- Faucet Seat Wrench
- Shower Valve Socket Wrench

