

58066V2

Installation Instructions

(Read all instructions carefully
before installing)

Seat replacement is
recommended with new stem
installations.

1. Turn off water supply to
faucet, remove handle cap,
retaining
screw and gently lift off
handle.
2. Unthread flange, then nipple
by turning counterclockwise.
3. Unthread bonnet and remove
stem using shower valve
socket wrench.
4. Insert seat wrench into faucet
body and turn
counterclockwise to remove
old seat.
5. Place new seat into faucet
body and tighten with seat
wrench.
6. Thread new stem unit into
faucet body.
7. Thread nipple into bonnet nut,
then thread flange onto
nipple.
8. Replace handle, retaining
screw and handle cap.
9. Turn on water supply and
check for leaks.

Tools needed for installation:

- Screwdriver
- Faucet Seat
Wrench
- Shower Valve Socket
Wrench

