


58250 - Installation Instructions


First remove old spout by placing a piece of wood, such as a hammer handle, in the spout and turning it counter clockwise.



FOR 1/2" COPPER PIPE CONNECTION

Tools Required: Hex Wrench (Included)

1. The length of copper pipe (B) from the finished wall should be at least 1" to maximum 2".
2. Trim the end of copper pipe. Chamfer the pipe end (B) and remove all burrs to avoid nicking the O-ring.
3. Loosen the set screw. Slip the adapter (C) onto copper pipe (B) so back end of adapter is flush with the finished wall. Tighten with hex wrench (D).



CAUTION: DO NOT OVERTIGHTEN. OVERTIGHTENING CAN LEAD TO CRACKING AND LEAKING LONG AFTER INSTALLATION.

4. Slide the rubber gasket (E) onto copper pipe (B) flush against the adapter (C).
5. Wrap the threads of adapter (C) with pipe thread tape. Thread tub spout (A) onto copper pipe (B) clockwise, hand tighten.

FOR 1/2" MALE THREADED CONNECTIONS

1. Wrap threaded wall tubing (G) with pipe thread tape*.
2. Thread plastic reducing adapter (H) onto threaded wall tubing (G), hand tighten. Wrap threads of plastic reducing adapter (H) with pipe thread tape*.
3. Insert the rubber gasket (E) into the tub spout (A).
4. Thread tub spout (A) onto plastic reducing adapter (H), hand tighten clockwise, until spout (A) is flush with back of plastic reducing adapter (H).

FOR 3/4" THREADED MALE CONNECTIONS

1. Wrap the threaded end of wall pipe (F) with pipe thread tape*.
2. Thread tub spout (A) onto the 3/4" wall pipe (F) clockwise, hand tighten.

*NOTE: To ensure pipe thread tape performs properly, regardless of tape thickness, it is recommended to wrap at least 6 times around or more.